

Elite Series Humidifiers Residential Whole-House (GFI #5705 & 5710)

GeneralAire[®] Models 570M & 570A

Flow Through Humidifiers

Breathe Healthier Control Indoor Humidity.

Installing a GeneralAire[®] Whole House Humidifier can reduce allergy and asthma symptoms, minimize risk of infection, protect valuables (such as furniture, woodwork and musical instruments) *and* save you money.



How the 570 Works:

Your furnace sends warm air through the unit, evaporating water within. Moistened air is then delivered throughout your home via your home's duct system to keep your air healthy.

Details inside or go to: www.generalfilters.com/model570

Install A Humidifier In Your Home To:

Protect your family's health:

Low humidity is where viruses can thrive and cause your throat and nasal passages to dry. This leads to nose bleeds, increased risk of infection, colds, flu and other respiratory ailments. Dry air can trigger asthma and allergy symptoms. Air that's too dry causes dry/ itchy/cracked skin.

Maintenance

Maintenance of your new GeneralAire[®] 570 Elite Series Flow Through Humidifier is minimal. To ensure peak performance and reliable operation, simply change your Vapor Pad[®] once per year! Go to www.generalfilters.com / support center / video library to view a video demonstrating how to change your Vapor Pad[®]. The 570 requires Vapr

Protect your valuables:

Dry air in your home can cause expensive artwork, wood flooring, cabinets, furniture and musical instruments to crack. Dry air increases annoying static shocks that can damage electronics.

Save money:

Since dry air can cause woodwork to crack, resulting gaps in windows & doors let cold outside air in. In addition, dry air feels colder. Take the chill out with an 570. Turn your thermostat down and save money.

Why A Whole-House Unit?

- Treats Your Whole House 24 / 7 / 365
- Requires Minimal Maintenance
- Out of Site
- Quiet



General Filters, Inc. 43800 Grand River Avenue Novi, Michigan 48375 Toll Free: (866) 476-5101 www.generalaire.com



Canadian General Filters, Ltd. 400 Midwest Rd. Toronto, ON M1P3A9 Canada Toll Free: (888) 216-9184 www.cgfproducts.com





GENERAL FILTERS

INCORPORATED

Elite Series Humidifiers Residential Whole-House (GFI #5705 & 5710)

Easy-Access Lift-Off Cover - For simple Vapor Pad® replacement

- Constructed with an ultra-violet stable

- Easy to remove. No tools needed.

automotive-grade plastic for long-lasting

and maintenance

durability.

- Easy to clean.

Damper Control

- Open during use.

- Can be mounted to the

Bypass Duct

left or right.

GeneralAire[®] Models 570M & 570A **Flow Through Humidifiers**

Cover Release Tabs

and lift off top tab.

when fully engaged.

Water Drain Tube

from your humdifier.

Water Intake Valve

- Water automatically drains

- Water is automatically distributed

throughout the Vapor Pad®.

- To remove cover: Gently release tab

at bottom of unit, pull cover away

- To replace cover: Hang first on top

tab, hear bottom tab "click" in place





Designed & Assembled in Michigan, USA

Included With M Models MHX3C Manual Humidistat

- Easy-to-Use Dial.
- Contemporary Design.
- Simply Turn The Dial To The Desired Humidity Level. Towards 75 = More Humidity / Towards 10 = Less Humidity.

Save Water! With the Water Savor™ Controller!

- Reduce water going down the drain from your humidifier by a minimum of 50%; even more with customized settings!
- Learn more at www.generalfilters.com.

Winter Settings

During winter months, be sure the water supply is turned on, your damper control is set to "Open" or "Winter", and your humidistat is set somewhere between 40% and 60%.

Spec Sheets Are Available On www.GeneralFilters.com (Support / Literature).

Our Brands GENERALAire General

Gar 💮 Ber



General Filters, Inc. 43800 Grand River Avenue Novi, Michigan 48375 Toll Free: (866) 476-5101 www.generalaire.com



Canadian General Filters, Ltd. 400 Midwest Rd. Toronto, ON M1P3A9 Canada Toll Free: (888) 216-9184 www.cgfproducts.com

Included With A Models **GFX3 Automatic Humidistat**

- Easy To Install.
- Extremely Accurate.
- Contemporary Design.
- Can Be Used In Automatic Or Manual Mode.
- Easy To Read Digital Backlit Display.

Replacement Vapor Pad®

GFI #7900: GA10

(Replace At The Start Of Each Heating Season)



How Much Humidity Do I Need?

Ideally, your home's humidity levels should stay between 40% and 60%. Outside that range, your risk of being adversely affected increases.







ICHIGAN®